

45055| Coaxial Cable Tester

Applications:

The Tempo 45055 Coaxial Cable Tester is intended to test the integrity of coaxial cable with BNC or F connectors when used with the terminators supplied. Provides quick verification of opens or shorts in either the conductor or the shield of coax cable.



BENEFITS

- Simple one-button operation provides pass/fail indication.
- Remote terminator allows testing of cables before or after installation.
- Remote terminator allows testing of cables before or after installation.
- Clear red/green LED indication fo short or open conditions.
- Standard BNC- and F-type female connectors.
- Battery operated (9V included).
- Lifetime limited warranty.

45055| Coaxial Cable Tester

OPERATION

1. Check the battery with a voltage tester to be sure it is fully charged.
2. See the illustration. Connect one end of the cable to be tested to the appropriate output jack of the tester. Connect the appropriate terminator to the other end of the cable. If the LED glows red, the cable has a short circuit. Repair or replace the cable.
3. Press the PRESS TO TEST button. If the LED glows green, the cable is in good condition. If the LED does not glow at all, the cable has an "open" or a break. Repair or replace the cable.

